



Таблица точек, координат и линий

№ п/п	Код	Координаты	Длина линии
№ п/п	А	Б	
1	А18В+42.8	Б50+31.4	19,76
2	А18В+42.8	Б50+42.20	19,76
3	А18В+42.8	Б50+44.18	19,76
4	А18В+42.8	Б50+46.22	19,76
5	А18В+42.8	Б50+48.26	19,76
6	А18В+42.8	Б50+50.30	19,76
7	А18В+42.8	Б50+52.34	19,76
8	А18В+42.8	Б50+54.38	19,76
9	А18В+42.8	Б50+56.42	19,76
10	А18В+42.8	Б50+58.46	19,76
11	А18В+42.8	Б50+60.50	19,76
12	А18В+42.8	Б50+62.54	19,76
13	А18В+42.8	Б50+64.58	19,76
14	А18В+42.8	Б50+66.62	19,76
15	А18В+42.8	Б50+68.66	19,76
16	А18В+42.8	Б50+70.70	19,76
17	А18В+42.8	Б50+72.74	19,76
18	А18В+42.8	Б50+74.78	19,76
19	А18В+42.8	Б50+76.82	19,76
20	А18В+42.8	Б50+78.86	19,76
21	А18В+42.8	Б50+80.90	19,76
22	А18В+42.8	Б50+82.94	19,76
23	А18В+42.8	Б50+84.98	19,76
24	А18В+42.8	Б50+87.02	19,76
25	А18В+42.8	Б50+89.06	19,76
26	А18В+42.8	Б50+91.10	19,76
27	А18В+42.8	Б50+93.14	19,76
28	А18В+42.8	Б50+95.18	19,76
29	А18В+42.8	Б50+97.22	19,76
30	А18В+42.8	Б50+99.26	19,76
31	А18В+42.8	Б50+101.30	19,76
32	А18В+42.8	Б50+103.34	19,76
33	А18В+42.8	Б50+105.38	19,76
34	А18В+42.8	Б50+107.42	19,76
35	А18В+42.8	Б50+109.46	19,76
36	А18В+42.8	Б50+111.50	19,76
37	А18В+42.8	Б50+113.54	19,76
38	А18В+42.8	Б50+115.58	19,76
39	А18В+42.8	Б50+117.62	19,76
40	А18В+42.8	Б50+119.66	19,76
41	А18В+42.8	Б50+121.70	19,76
42	А18В+42.8	Б50+123.74	19,76
43	А18В+42.8	Б50+125.78	19,76
44	А18В+42.8	Б50+127.82	19,76
45	А18В+42.8	Б50+129.86	19,76
46	А18В+42.8	Б50+131.90	19,76
47	А18В+42.8	Б50+133.94	19,76
48	А18В+42.8	Б50+135.98	19,76

Таблица точек, координат, линий

№ п/п	Код	Координаты	Длина линии
№ п/п	А	Б	
1	А18В+42.8	Б50+31.4	207,14
2	А18В+42.8	Б50+42.20	2,93
3	А18В+42.8	Б50+44.18	4,671
4	А18В+42.8	Б50+46.22	4,671
5	А18В+42.8	Б50+48.26	4,671
6	А18В+42.8	Б50+50.30	4,671
7	А18В+42.8	Б50+52.34	4,671
8	А18В+42.8	Б50+54.38	4,671
9	А18В+42.8	Б50+56.42	4,671
10	А18В+42.8	Б50+58.46	4,671
11	А18В+42.8	Б50+60.50	4,671
12	А18В+42.8	Б50+62.54	4,671
13	А18В+42.8	Б50+64.58	4,671
14	А18В+42.8	Б50+66.62	4,671
15	А18В+42.8	Б50+68.66	4,671
16	А18В+42.8	Б50+70.70	4,671
17	А18В+42.8	Б50+72.74	4,671
18	А18В+42.8	Б50+74.78	4,671
19	А18В+42.8	Б50+76.82	4,671
20	А18В+42.8	Б50+78.86	4,671
21	А18В+42.8	Б50+80.90	4,671
22	А18В+42.8	Б50+82.94	4,671
23	А18В+42.8	Б50+84.98	4,671
24	А18В+42.8	Б50+87.02	4,671
25	А18В+42.8	Б50+89.06	4,671
26	А18В+42.8	Б50+91.10	4,671
27	А18В+42.8	Б50+93.14	4,671
28	А18В+42.8	Б50+95.18	4,671
29	А18В+42.8	Б50+97.22	4,671
30	А18В+42.8	Б50+99.26	4,671
31	А18В+42.8	Б50+101.30	4,671
32	А18В+42.8	Б50+103.34	4,671
33	А18В+42.8	Б50+105.38	4,671
34	А18В+42.8	Б50+107.42	4,671
35	А18В+42.8	Б50+109.46	4,671
36	А18В+42.8	Б50+111.50	4,671
37	А18В+42.8	Б50+113.54	4,671
38	А18В+42.8	Б50+115.58	4,671
39	А18В+42.8	Б50+117.62	4,671
40	А18В+42.8	Б50+119.66	4,671
41	А18В+42.8	Б50+121.70	4,671
42	А18В+42.8	Б50+123.74	4,671
43	А18В+42.8	Б50+125.78	4,671
44	А18В+42.8	Б50+127.82	4,671
45	А18В+42.8	Б50+129.86	4,671
46	А18В+42.8	Б50+131.90	4,671
47	А18В+42.8	Б50+133.94	4,671
48	А18В+42.8	Б50+135.98	4,671